

TOP MOUNT INSTALATION INSTRUCTIONS

1. MEASURE AND MARK THE MOUNTING HOLE LOCATIONS THAT MATCH THE TRAILER MOUNTING PLATE. MAKE SURE TO POSITION THE MEW BOARDS, THE SAME AS THE OLD BOARDS.
2. USING A 1" WIDE "SPADE-BIT" COUNTER-BORE THE TOPS OF THE BOARDS APPROXIMATELY 5/8" DEEP.
3. USING A .343" DRILL BIT, DRILL A THRU-HOLE, THROUGH THE CENTER OF THE COUNTER-BORE.
4. USE A 5/16-18 x 1-1/2" HEX-HEAD BOLT, ALONG WITH A 7/8" WIDE FLAT WASHER UNDER THE HEAD OF THE BOLT
5. ATTACH WITH A 5/16-18 HEX NUT AND A LOCK WASHER.

IK-201 DRILL BIT KIT



1" WIDE FLAT SPADE BIT



.343" DRILL BIT


IK-202 HARDWARE KIT



HEX-HEAD BOLT



FLAT-WASHER



LOCK WASHER



HEX NUT



CHOICE EQUIPMENT CO. INC.
5974 US HWY. 129 N. UNIT O
PENDERGRASS GA. 30567

UBB-MOUNT COUNTER BORE

INTL. JL

8-30-17

SCALE: 1:5

SHEET 1 OF 1